

## THIS UPDATE IS FOR VERSION 5.0 Lights with audio jack.

-THIS UPDATE MUST BE DONE FROM A PC.

-PLEASE READ STEPS 1 & 2 BEFORE you start the update.

This update will factory reset your light.


### 1.) Download the Updater

\*\*Make sure that you select to save the updater file **to your desktop** when it prompts you for a location.


Once you download the file to your desktop, **MAKE SURE THE GOAL LIGHT IS CONNECTED TO THE USB PORT. ON YOUR COMPUTER** BEFORE YOU CLICK ON THE UPDATER!

NOTE\*\* It is important that any other devices that are connected to USB ports you disconnect them until you're done with the update (except the keyboard).

### 2.) Double click on the Updater icon. It should open a window asking permission to run the program, click YES.



3.) It will then open a black box and if your Goal Light is connected it will say: connected to com (and a number here). If there is no number after "com" it does not see your Goal Light. You will need to close the program, plug the Goal Light into a different USB port and try again.



4.) It will then say "press any key". Once you press any key it will start the update which should only take about 45 seconds. It will scroll text then you will see a progress bar counting to 100.

5.) When it gets to 100, it finishes the update, closes the program and will delete the program from your computer.

You are all set now with the new working update. Your light has been factory reset you can do the setup again from your phone.